

## PLAYTIME BASICSHOPPER



19 86 -- 7 25 60

19 89 -- 7 25 91

### BASICShopper

|        | Cod.             | mm              | Um | Pz | Box |
|--------|------------------|-----------------|----|----|-----|
| SMALL  | 19 -- 16 7 25 -- | 160 x 70 x 215  | PA | 25 | 18  |
| MEDIUM | 19 -- 24 7 25 -- | 240 x 100 x 310 | PA | 25 | 10  |
| LARGE  | 19 -- 36 7 25 -- | 360 x 120 x 410 | PA | 25 | 8   |

## TRAVEL BASICSHOPPER



70

### BASICShopper

|        | Cod.             | mm              | Um | Pz | Box |
|--------|------------------|-----------------|----|----|-----|
| SMALL  | 19 45 16 7 25 70 | 160 x 70 x 215  | PA | 25 | 18  |
| MEDIUM | 19 45 24 7 25 70 | 240 x 100 x 310 | PA | 25 | 10  |
| LARGE  | 19 45 36 7 25 70 | 360 x 120 x 410 | PA | 25 | 8   |